
ENGINE OIL

Engine Oil Level Check

Check the engine oil level each day before riding the motorcycle. The level must be maintained between the upper and lower level marks in the inspection window.

To check the oil level:

1. Start the engine and let it idle for a few minutes. Make sure the low oil pressure indicator goes off. If the indicator remains flashing, stop the engine immediately.
2. Stop the engine and put the motorcycle on its center stand on level ground.
3. After a few minutes, check that the oil level is between the upper and lower level marks in the inspection window.
4. If required, remove the oil filler cap, over head cover and add the specified oil up to the upper level mark. Do not overfill.
5. Reinstall the oil filler cap, and over head cover. Check for oil leaks.

NOTICE

Running the engine with insufficient oil can cause serious engine damage.

