

Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, and how to use the throttle and brakes. It also provides important information on riding with cargo.

To protect your new engine and enjoy optimum performance and service life, refer to *Break-in Guidelines* (page 186).

For information about carburetor adjustment for riding at high altitude, see page 187.

Safe Riding Precautions	43
Off-Road Use Only	43
Keeps Hands and Feet on Controls	44
Control Speed	45
Use Care on Unfamiliar or Rough Terrain	46
Do Not Perform Stunts	47
Starting & Stopping the Engine	48
Preparation	48
Starting Procedure	49
Flooded Engine	52
How to Stop the Engine	52
Using the Recoil Starter	53
Shifting Gears	54
Riding in Reverse	61

(cont'd)