Troubleshooting

Engine Will Not Start ..... P. 136
Overheating (High coolant temperature indicator is on) ..... P. 137
Warning Indicators On or Flashing ..... P. 138
Low Oil Pressure Indicator ..... P. 138
PGM-FI (Programmed Fuel Injection) Malfunction Indicator Lamp (MIL) ..... P. 138
ABS (Anti-lock Brake System) Indicator ..... P. 139
Torque Control Indicator ..... P. 140
If the "–" Indicator is Blinking in the Gear Position Window While Riding ..... P. 141
Other Warning Indications ..... P. 142
Fuel Gauge Failure Indication ..... P. 142
Coolant Temperature Gauge Failure Indication ..... P. 142
Tire Puncture ..... P. 143
Electrical Trouble ..... P. 151
Battery Goes Dead ..... P. 151
Burned-out Light Bulb ..... P. 151
Blown Fuse ..... P. 154