# COMPETITION MAINTENANCE SCHEDULE

Check all items before each race.
Refer to REGULAR MAINTENANCE SCHEDULE (page 3-3) for regular (non-competition use) service intervals.

| ITEM | INSPECT FOR | ACTION AS REQUIRED | REFER TO PAGE |
|---|---|---|---|
| ENGINE OIL | Oil level, leakage | Supply or change | 3-10 |
| FUEL TANK | Damage, leakage | Replace | 3-5 |
| BRAKE SYSTEM | Brake lever free play, brake pedal height, braking, efficiency and wear beyond service limit | Adjust, tighten or replace | 3-20 |
| BRAKE FLUID | Fluid level, leakage | Supply or change | 3-19 |
| WHEELS/TIRES | Tire pressure, wear or damage, spoke tightness and rim lock tightness | Adjust, tighten or replace | 3-25 |
| DRIVE CHAIN | Slack, lubricate | Adjust, tighten or replace | 3-15 |
| SPROCKETS | Wear and secure installation | Tighten or replace | 3-15 |
| SEAT | Security | Tighten | 2-2 |
| CLUTCH DISCS | Proper operation, wear (NOTE 1) | Replace | 3-21 |
| AIR CLEANER ELEMENT | Contamination or tears | Clean or replace | 3-6 |
| ENGINE STOP SWITCH | Proper operation | Correct or replace | 17-15 |
| NUTS, BOLTS, FASTENERS | Tightness | Tighten | 3-24 |
| FUEL LINE | Deterioration, damage or leakage | Replace | 3-5 |
| VALVE CLEARANCE | Correct clearance | Adjust | 3-8 |
| CAM CHAIN | Excessive noise | Replace | 12-3 |
| ENGINE IDLE SPEED | Correct idle speed | Adjust | 3-13 |
| DECOMPRESSOR SYSTEM | Proper operation, lever free play | Adjust | 3-13 |
| SPARK PLUG | Tightness, proper heat range, spark plug wire looseness and damage | Tighten or replace | 3-7 |
| COOLING SYSTEM | Damage, leakage | Replace | 3-14 |
| STEERING HEAD | Free rotation of handlebar and steering stem nut tightness | Adjust or tighten | 3-25 |
| FRONT SUSPENSION | Smooth operation, no oil leaks, good boot condition and proper oil volume | Adjust or replace | 3-22 |
| REAR SUSPENSION | Smooth operation, no oil leaks and spring length | Adjust or replace | 3-23 |
| SWINGARM BEARINGS | Smooth operation | Lubricate or replace | 3-24 |
| REAR SUSPENSION LINKAGE BEARINGS | Smooth operation | Lubricate or replace | 3-23 |
| CONTROL CABLES | Smooth operation, inner cable damage, kinks and correct rooting | Lubricate or replace | 1- 20 |
| ENGINE MOUNTING BOLTS | Tightness | Tighten | 7-5 |
| SPARK ARRESTER | Clogged | Clean | 3-24 |

NOTE 1: Competition use necessitates more frequent service.