

7. After the oil has drained, install the drain bolt with new sealing washer and tighten to the specified torque:
22 lbf•ft (30 N•m, 3.1 kgf•m)
8. Pour the recommended oil into the crankcase, approximately:
1.1 US qt (1.0 l)
9. Install the oil fill cap/dipstick securely.
10. Start the engine and let it idle for 3-5 minutes. Stop the engine. Wait 2-3 minutes.
11. With the motorcycle held upright on level ground, check the oil level.
If needed, add oil ([page 65](#)) until it reaches the upper level mark. (Do not overfill.)
12. Check for oil leaks.
13. Install the engine guard.