


SHIFTING

The gearshift operation differs when stopping and when moving.

When stopping, change can be made from 4th to neutral directly with the 4-step rotary system.



(N) Neutral

(1) First

(2) Second

(3) Third

(4) 4th (Top)