

## Starting procedure

To restart a warm engine, follow the procedure for “High Air Temperature”.

### Normal Air Temperature

10° - 35 °C (50° - 95 °F)

1. With the engine cold, pull the choke knob (1) fully out.
2. Start the engine, leaving the throttle closed.

Do not open the throttle when starting the engine with the choke ON. This will lean the mixture, resulting in hard starting.

### NOTICE

Operating the engine with insufficient oil pressure can cause serious engine damage.

3. Immediately after the engine has started, activate choke knob (1) to keep idle

speed at:

1500 - 2000 min<sup>-1</sup> (rpm)

4. Approximately 30 seconds after the engine has started push the choke knob (1) fully in until it is completely closed.
5. If idling is unstable, open the throttle slightly.



(1) Choke knob