

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	→		ODOMETER READING[NOTE (1)]							
			x 1000 km	1	6	12	18	24	30	36	REFER TO PAGE	
			x 1000 mi	0,6	4	8	12	16	20	24		
			MONTHS		6	12	18	24	30	36		
	DRIVE CHAIN			EVERY 1000 km (600mi) I, L								82
	DRIVE CHAIN SLIDER										87	
	BRAKE FLUID	NOTE (4)					R			R	20	
	BRAKE PAD WEAR										96	
	BRAKE SYSTEM										20,96	
*	BRAKE LIGHT SWITCH										-	
*	HEADLIGHT AIM										-	
	CLUTCH SYSTEM										23	
	SIDE STAND										89	
*	SUSPENSION										-	
*	NUTS, BOLTS, FASTENERS										-	
**	WHEEL/TYRES										-	
**	STEERING HEAD BEARINGS										-	