

Removal from Storage

1. Uncover and clean the motorcycle. Change the engine oil if more than 4 month have passed since the start of storage.
2. Charge the battery as required. Install the battery.
3. Drain any excess aerosol rust-inhibiting oil from the fuel tank. Fill the fuel tank with fresh gasoline.
4. Perform all Pre-ride Inspection checks (page 86). Test ride the motorcycle at low speeds in a safe riding area away from traffic.

Remise en service

1. Découvrir et nettoyer la motocyclette. Changer l'huile du moteur si plus de quatre mois se sont écoulés depuis le début du remisage.
2. Contrôler le niveau d'électrolyte et charger la batterie comme nécessaire. Mettre la batterie en place.
3. Vidanger le réservoir d'essence du produit anti-corrosion résiduel et le remplir d'essence.
4. Effectuer tous les contrôles préalables (page 86). Essayer la machine à faible vitesse sur parcours facile en se tenant éloigné des zones encombrées.