



# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

<b>Importance of Maintenance</b> .....	P. 42	<b>Clutch</b> .....	P. 74
<b>Maintenance Schedule</b> .....	P. 43	<b>Throttle</b> .....	P. 77
<b>Maintenance Fundamentals</b> .....	P. 46	<b>Other Adjustments</b> .....	P. 78
<b>Tool Kit</b> .....	P. 57	Brake lever .....	P. 78
<b>Removing &amp; Installing Body Components</b> .....	P. 58	Rear Suspension .....	P. 79
Seat .....	P. 58	Headlight Aim .....	P. 80
Battery .....	P. 59		
<b>Engine Oil</b> .....	P. 60		
<b>Coolant</b> .....	P. 64		
<b>Brakes</b> .....	P. 66		
<b>Side Stand</b> .....	P. 69		
<b>Drive Chain</b> .....	P. 70		

