

INSTRUMENTS AND INDICATORS

The indicators are contained in the instrument panel. Their functions are described in the tables on the following pages.

- (1) Speedometer
- (2) Tachometer
- (3) Tachometer red zone
- (4) Neutral indicator
- (5) Coolant temperature meter
- (6) Low oil pressure indicator
- (7) Odometer/tripmeter display
- (8) Odometer/tripmeter select and reset button
- (9) Right Turn signal indicator
- (10) High beam indicator
- (11) Left Turn signal indicator

