


## Start Button

The start button (1) is next to the throttle grip. When the start button is pressed, the starter motor cranks the engine. See page 30 for the starting procedure.




(1) Start button

## Engine Stop Button

The engine stop button (1) is next to the left handlebar grip.

Push the button in and hold it in until the engine stops completely.



(1) Engine stop button