


Starting Procedure

To restart a warm engine, follow the procedure for “High Air Temperature”.

Normal Air Temperature

10° - 35° C (50° - 95° F)

1. Pull the choke lever (1) up all the way to Fully ON (A).



(1) Choke lever

(A) Fully ON

(B) Detent position

(C) Fully OFF

2. With the throttle closed, press the starter button.
3. Immediately after the engine starts, push the choke lever (1) down to the Detent Position (B).

NOTICE

Extended use of the choke may impair piston and cylinder wall lubrication and damage the engine.

4. Warm up the engine by opening and closing the throttle slightly.
5. About a half minute after the engine starts, push the choke lever (1) down all the way to Fully OFF (C).
6. If idling is unstable, open the throttle slightly.