Turn Signal Switch

Move the switch to \Leftarrow (L) to signal a left turn, to \Rightarrow (R) to signal a right turn; the appropriate turn signal and indicator will blink. The switch returns to center when it is released. The indicator and turn signal will automatically stop blinking after completing the turn. Blinking may be stopped manually by pushing in on the switch.

