
TRAVEL TRUNK AND SADDLEBAGS

The travel trunk and saddlebags are for lightweight items. Do not carry more than 9.0 kg (20.0 lbs) in the trunk or in each saddlebag.

To Lock & Unlock the Travel Trunk & Saddlebags

The travel trunk and saddlebags can be locked and unlocked with the ignition key or remote transmitter.

To use the remote transmitter, see page 64.

To unlock:

Insert the ignition key and turn it clockwise.

To lock:

Insert the ignition key and turn it counterclockwise.

