


## AM/FM Radio

Your Honda's audio system provides clear reception on each band while the preset buttons allow you to easily select your favorite stations. In some countries, you can also utilize many convenient features provided by the Radio Data System (RDS).

### Power Switch:

To turn the audio system on — push the AUDIO button.



To turn the audio system off — push and hold the AUDIO button until you hear a beep. The display will show the Odometer/Tripmeter only.

CD is optional equipment. This is only indicated if installed.

### Switch Output:

When the audio system is turned on, you can switch its output between Speaker and Headset. (Headset is optional equipment.)

- Pushing the AUDIO button switches the output.

