

FEATURES (Not required for operation)

TP Alarm

If the signal from a TP station becomes weak while you are listening to the radio, “TP” indicator will disappear, and about 70 seconds later an alarm will sound for 0.5 second to tell you to tune to another TP station.

If the TP indicator goes out again after the reception is recovered, the system gives off the alarm again for 0.5 second. An alarm will also sound if you try to access tuning or preset operation after the TA function has been turned on or when the TP indicator is not turned on.

PTY/News Interrupt Function

To activate this function, up the NEWS lever, “NEWS” will light on the display.

For the volume level information is the same as for TA function (see page 85).

Your audio system has another interrupt function (including TA function). The priority of interrupt is in the order of “NEWS”, “TA”, and “ALARM”. To activate the other interrupt function, turn off the currently activated interrupt function.

PTY Alarm

PTY code “ALARM” is used for emergency announcements, such as natural disasters. When this code is received, “ALARM” goes on the display and the volume is changed. When the alarm is cancelled, the system will return to the normal operation mode.