Brakes - Check operation of front and rear brakes. Adjust free play if incorrect.

Free play is the distance the brake lever moves before the brake starts to engage.

<Front>



