After installing the wheel, apply the brakes several times, and check for free wheel rotation when released.

AWARNING

* If a torque wrench was not used for installation, see your authorized Honda dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of breaking capacity.