

## **REMOVAL FROM STORAGE**

1. Uncover and clean the motorcycle.  
Change the engine oil if more than 4 months have passed since the start of storage.
2. Charge the battery as required. Install the battery.
3. Fill the fuel tank fully.
4. Perform all Pre-ride Inspection checks (page 51).  
Test ride the motorcycle at low speeds in a safe riding area away from traffic.