


## HANDLEBAR CONTROLS

### Headlight Switch (1) (DK type)

- ☰ — Headlight, taillight, and meter light will be on when the engine is running.
- — Headlight, taillight and meter light off.

### DK type




- (1) Headlight switch
- (2) Starter button

### Starter Button (2)

The starter button (2) is below the headlight switch (1).

When the starter button is pressed, the starter motor cranks the engine. See page 33 for the starting procedure.

### U type



- (2) Starter button