

CONTENTS

MAINTENANCE

Page		Page	
64	MAINTENANCE	84	FRAME/WHEELS/ BRAKES
65	Maintenance Schedule	84	Front Wheel Removal
67	Tool Kit	90	Rear Wheel Removal
68	Serial Numbers	93	Brake Pad Wear
68	Colour Label	94	Brake System Inspection
69	Maintenance Precau- tions	95	Side Stand
70	Cover Removal		
		96	ELECTRICAL
75	FILTERS/LUBRICATION	96	Battery
75	Engine Oil And Filter	98	Fuse Replacement
78	Air Cleaner		
		103	CLEANING
80	ENGINE		
80	Spark Plugs	105	STORAGE GUIDE
82	Idle Speed	105	Storage
		106	Removal From Storage
83	DRIVE TRAIN		
83	Final Drive Oil	107	SPECIFICATIONS
		110	NOISE EMISSION (AUSTRALIA ONLY)