

# MAINTENANCE

---

For related torque specifications, see page 108 . Cover both sides of the front wheel with protective tape or an equivalent.  
The numbers indicate the disassembly sequence.

