


---

### Front Turn Signal Bulb

1. Remove the mirror cover (page 65 ).
2. Turn the socket 90° counterclockwise, then pull it out toward you.
3. Pull out the bulb without turning.
4. Install a new bulb in the reverse order of removal.



### Rear Turn Signal Bulb

1. Remove the seat (page 57 ).
2. Turn the socket 90° counterclockwise, then pull it out toward you.
3. Pull out the bulb without turning.
4. Install a new bulb in the reverse order of removal.

