


## Helmet Holder

The helmet holder (1) is under the right handlebar. To use the helmet holder, hang your helmet on holder hook.

### WARNING

*\* Do not operate the TRX with a helmet attached to the holder: your ability to steer will be impaired. The helmet holder is designed for use while the TRX is parked.*



(1) Helmet holder

## Throttle Lever

The throttle lever (1) is next to the right handlebar grip and is operated by the rider's thumb. Pressing the lever forward opens the throttle. When the lever is released, spring tension closes the throttle automatically.

(1) Throttle lever

(A) Open