## **MAINTENANCE AND REPAIRS**

## **MAINTENANCE SCHEDULE**

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate	EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
* FUEL LINE	YEAR I			
* FUEL STRAINER SCREEN	YEAR C			88, 89
* THROTTLE OPERATION		ı	I	91
* CARBURETOR CHOKE			1	96
AIR CLEANER	(NOTE 1)		С	92-94
AIR CLEANER CASE DRAIN TUBE	(NOTE 2)		I	95
SPARK PLUG			1	106, 107
* VALVE CLEARANCE		ı	ı	107
ENGINE OIL		R	R	28, 99-103
ENGINE OIL FILTER		R	R	101 – 103
* CARBURETOR IDLE SPEED		ı	I	96-98
FINAL DRIVE OIL AND FRONT DIFFERENTIAL OIL	YEAR I, 2 YEARS R			104, 105
BRAKE FLUID	(NOTE 3)		l	118, 119