

Skidding	62
Spark arrester	130
Spark knock	84
Spark plug	102
Specifications	140
Stalling on a hill	65
Starter button	16
Starting primer knob	16
Storage compartment	31
Storing procedures	137

T

Throttle	
Cable	86
Lever	18, 86
Tires	
Inflation and air pressure	124
Repairing	127
Specifications	125
Tread condition	126
Tool kit	80
Trailer hitch	30
Trailer towing	
Operational guidelines	38
Weight limits	37
Transporting procedures	134
Turning	
On level ground	60
On slopes	73

V

Valve clearance	103
-----------------------	-----

W

Warning labels	7
Warranty service	144
Water	
Draining from brakes	122
Riding through	75
Weight limits	37
Wheel removal	123
Wiring diagram	142