

I

Idle speed adjustment	97
Ignition switch	14
Indicator lamp	
Neutral indicator lamp	23
Reverse indicator lamp	23
Inspection, pre-ride	38

L

Loading	
Loading guidelines and procedures.....	42
Weight limits.....	41
Lubrication	
(see Engine oil, Gear case oil and differential oil)	

M

Maintenance	
Precautions	84
Schedule	83
Modifications	46

N

Neutral indicator lamp.....	23
-----------------------------	----

O

Obstacles, riding over.....	80
Odometer	24
Oil (see Engine oil, Gear case oil and differential oil)	
Oil filler cap/dipstick	31, 100
Oil filter, changing.....	102
Owner's manual compartment	35