



## Tool Kit

---

The tool kit (1) is stored in the storage compartment (2) below the rear cargo rack.



To open the compartment, unhook the rubber strap (3).

The gear change tool (4) is stored underside of the seat.

An optional, larger tool kit may be available. Check with your Honda dealer's parts department.

### REAR

### SEAT UNDERSIDE



- (1) tool kit
- (2) storage compartment

- (3) rubber strap
- (4) gear change tool

