

MAINTENANCE SCHEDULE

		FREQUENCY ITEMS	Whichever comes first	INITIAL	REGULAR		Refer to page	
				MAINTENANCE	MAINTENANCE INTERVAL			
			↪	mi	600	1200		
			NOTE	km	1000	2000		
			HOURS	20	100	200		
EMISSION RELATED ITEM	*	FUEL LINE				I	—	
	*	THROTTLE OPERATION				I	104	
	*	CARBURETOR CHOKE				I	109	
		AIR CLEANER	(NOTE 1)			C	C	105 – 107
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	108
		SPARK PLUG				I	I	120 – 121
	*	VALVE CLEARANCE			I	I	I	121
		ENGINE OIL			R	R	R	37, 112 – 116
		ENGINE OIL FILTER			R	R	R	112 – 116
	*	ENGINE IDLE SPEED			I	I	I	110

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate