

Indicators & Display

6	Odometer/tripmeter select button	Selects display of the odometer or tripmeter. Resets the tripmeter to zero (0) (page 20).
7	Hourmeter/digital clock select button	Selects display of the hourmeter or digital clock (pages 21 , 22).
8	Hour select button	Advances the hour displayed by the digital clock (page 22).
9	Minute select button	Advances the minutes displayed by the digital clock (page 22).