

Instruments & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Component Locations	10
Indicator	13
High Coolant Temperature Indicator	13
Controls & Features	14
Fuel Valve	14
Choke Lever.....	15
Hot Start Lever.....	16
Ignition Switch.....	17
Kickstarter.....	18
Engine Stop Switch.....	19
Headlight Switch.....	20
Headlight Dimmer Switch.....	20
Throttle Lever	21
Clutch Lever.....	21
Front Brake Lever	22
Rear Brake Pedal.....	22
Parking Brake.....	23
Flag Pole Bracket	24