

Maintenance Schedule

ITEMS		FREQUENCY	WHICHEVER COMES FIRST ⇨ NOTE	mi km HOURS	INITIAL	REGULAR		Refer to page	
					MAINT.	MAINT. INTERVAL			
					100	600	1200		
	DRIVE CHAIN		NOTE 1,2		I,L	I,L EVERY 300mi (500km) or 50 operating hours		145	
	DRIVE CHAIN SLIDER							147	
NON EMISSION RELATED ITEMS	* BRAKE FLUID		NOTE 3					127	
	* BRAKE PAD WEAR		NOTE 1,2					131	
	* BRAKE LIGHT SWITCH							134	
	BRAKE SYSTEM							127	
	SKID PLATES, ENGINE GUARD								144
	* CLUTCH SYSTEM							110	
	* SUSPENSION							121	
	* SPARK ARRESTER						C	C	119
	* NUTS, BOLTS, FASTENERS								—
	** WHEELS/TIRES								—
	** STEERING HEAD BEARINGS								—
	** STEERING SHAFT HOLDER BEARINGS								—
	** STEERING SYSTEM								—

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 198).

** In the interest of safety, we recommend these items be serviced only by your Honda dealer.