

Indicators & Displays

5	Neutral indicator	Lights when the transmission is in neutral. <i>Lamp Check</i>
6	Reverse indicator	Lights when the transmission is in reverse. <i>Lamp Check</i>
7	Multi-function display	The display includes the following functions. <i>Display Check.</i>
	Drive mode indicator	Shows the driving mode (page 20).
	Gear position indicator	Shows the gear position. (page 21)
	Speedometer	Shows riding speed.
	Fuel gauge	Shows approximate fuel supply available (page 29).
	Oil change indicator	Lights when specified maintenance interval for engine oil change is reached (page 22).
	Odometer	Shows accumulated mileage (page 23).
	Tripmeter	Shows mileage per trip (page 23).
	Hourmeter	Shows hours and tenths of hours of engine operation (page 25).
	Digital clock	Shows the time (hours and minutes) (page 26).
8	Hour select button	Advances the hour displayed by the digital clock (page 22).
	GPS button (TRX500 FGA)	This button is used to select the GPS navigation mode.