

To Change the Coordinates for an Existing Waypoint Number:

Follow steps 1 – 4 under *Advance Waypoint Selection* (page 67) and “overwrite” your previous waypoint.

To Delete the Coordinates for an Existing Waypoint Number:

1. Follow steps 1 – 4 under *Advance Waypoint Selection* (page 67).
2. Within 5 seconds, press and hold the GPS button and WP button for about 2 seconds. The waypoint will delete.

To Delete the Coordinates for all Existing Waypoint Number:

1. Follow steps 1, 2 and 4 under *Advance Waypoint Selection* (page 67).
2. Within 5 seconds, press and hold GPS button, WP button, plus button and minus button for about 2 seconds. The waypoints will delete.

Determining the Coordinates of Your Current Position

1. If your current position is not already marked, mark it (page 65).
2. Press and hold the WP button until the display begins blinking.
3. While the display is still blinking, press and hold the WP button again until the display shows LAT degrees and minutes.
4. Tap (do not hold) the WP button repeatedly to sequence through the coordinates display.
5. Tap the WP button again to return to the distance to waypoint display.