




Indicators & Displays

(For TRX500FGA/FPA)

To reset the indicator, press and hold both the odometer/tripmeter select button (2) and digital clock/hourmeter select button (4) for more than 2 seconds. The indicator will disappear.



- (1) oil change indicator
- (2) odometer/tripmeter select button

- (4) digital clock/hourmeter select button (TRX500FGA/FPA)

If the oil is changed before the oil change indicator appears, be sure to reset the oil change indicator after changing the oil. The indicator will appear for 2 seconds, then disappear. This means the indicator is reset.

