




GPS Mode

Advanced Waypoint Selection

Advanced Latitude & Longitude Entry Sequence					
latitude	1	--° (degrees)	longitude	1	---° (degrees)
	2	--' (minutes)		2	--' (minutes)
	3	-- (seconds)		3	-- (seconds)
	4	.-" (tenths of second)		4	.-" (tenths of second)

To input a waypoint value using latitude and longitude coordinates:

(For TRX500FGA)



- (1) waypoint number
- (2) plus button
- (3) minus button
- (4) WP button
- (5) waypoint distance

