




# GPS Mode

To input a waypoint value using latitude and longitude coordinates:

(For TRX500FPA)



- (1) GPS/WP button
- (2) waypoint number
- (3) plus button
- (4) minus button
- (5) waypoint distance

(cont'd)

