

Engine Oil & Filter

Changing Engine Oil & Filter

Refer to Safety Precautions on page 147.

Your ATV's oil filter has very specific performance requirements. Use a new Honda Genuine oil filter specified for your model or a filter of equal quality.

NOTICE

Using the wrong oil filter may result in leaks or engine damage.

This procedure requires mechanical skill and professional tools such as a torque wrench and oil filter wrench, as well as a means for disposing of the drained fluid (page 238). If you do not have the skills or the tools, see your Honda dealer.

Drain the Engine Oil:

1. With the ATV on level ground, start the engine and let it idle for 5 minutes.

(cont'd)

Servicing Your Honda 167

