

# Quick Reference

---

|                         |   |
|-------------------------|---|
| Scheduled Maintenance   | Initial: 100 miles (150 km)<br>Regular: every 600 miles (1,000 km)  |
| Pre-ride Inspection     | Check the following items each time before you ride (page 79): engine oil, radiator coolant, fuel, tires, driveshaft boots, nuts & bolts, underbody & exhaust system, air cleaner housing drain tube, leaks, loose parts, cables, lights, throttle, brakes, switches, steering. |
| Fuel/Capacity           | unleaded gasoline, pump octane number 86 or higher<br><b>4.44 US gal (16.8 l)</b>   |
| Engine Oil              | API Service Classification SG or higher except oils labeled as energy conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 or HP4 (without molybdenum additives) 4-stroke oil or equivalent  |
| Maximum Weight Capacity | <b>485 lbs (220 kg)</b><br>rider, all cargo and accessories   |