



Is Your ATV Ready to Ride?

Check these items after you get on the ATV:

Throttle Check the freeplay and adjust if needed. Press the throttle to make sure it moves smoothly without sticking, and snaps shut automatically when it is released, in all steering positions (page 113).

Brakes Squeeze the front brake lever and step on the rear brake pedal to check that the controls operate normally. Make sure there is no brake fluid leakage (page 126).

*Clutch Lever/
Parking Brake Lever* Check for smooth operation and adjust if needed (pages 115 , 132).

*Reverse Assist
Lever* Make sure the reverse assist lever operates smoothly without sticking.

Indicators Turn the ignition switch ON (I) and check for normal operation of the indicators (page 14).

*Headlight and
Headlight Dimmer
Switch* Check for proper function (page 19).

Engine Stop Switch Check for proper function (page 18).

Steering Check that the wheels turn properly as you steer the handlebar. Move the handlebar right and left and check that there is no excessive backlash.

Remember, be sure to take care of any problem you find, or have your Honda dealer correct it before you ride.

34 Before Riding

