


Operating Control

Choke Lever

N

LEFT SIDE



(1) choke lever

The choke lever may be used when starting the engine. See page 56 .