


Initial Display

When the ignition switch is turned ON, the multi-function display (1) will temporarily show all the modes and digital segments so you can make sure the liquid crystal display is functioning properly.

The unit “km” (2) will be displayed only for F, III F, ED, II ED, III ED and U type.

The unit “mile” (3) will be displayed only for E, IVE type.

Digital clock (4) and tripmeter (5) will reset if the battery is disconnected.



- (1) Multi-function display
- (2) “km”
- (3) “mile”
- (4) Digital clock
- (5) Tripmeter