

ITEM	FREQUENCY	NOTE	ODOMETER READING (NOTE (1))							*Refer to Service Manual	
			X 1,000KM	1	6	12	18	24	30		36
			X 1,000MI	0.6	4	8	12	16	20		24
		MONTH	6	12	18	24	30	36			
	DRIVE CHAIN		EVERY 1,000KM (600MI) I,L							*	
	DRIVE CHAIN SLIDER									-	
	BRAKE FLUID	(NOTE 4)				R			R	-	
	BRAKE SHOE/PAD WEAR									-	
	BRAKE SYSTEM									-	
*	BRAKE LIGHT SWITCH									-	
*	HEADLIGHT AIM									-	
	CLUTCH SYSTEM									-	
	SIDE STAND									-	
*	SUSPENSION									*	
*	NUTS, BOLTS, FASTENERS									-	
**	WHEELS/TYRES									-	
**	STEERING HEAD BEARINGS									*	