

ITEM	FREQUENCY	WHICHEVER → COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]							Refer to page	
			× 1,000 km	1	6	12	18	24	30		36
			× 1,000 mi	0.6	4	8	12	16	20		24
		NOTE	MONTH								
	FINAL DRIVE OIL				I		I		R		70
	BRAKE FLUID	NOTE (3)			I	I	R	I	I	R	17
	BRAKE PAD WEAR				I	I	I	I	I	I	83
	BRAKE SYSTEM					I		I		I	17, 83
*	BRAKE LIGHT SWITCH					I		I		I	—
*	HEADLIGHT AIM					I		I		I	41
	CLUTCH SYSTEM					I		I		I	19
	CLUTCH FLUID	NOTE (3)			I	I	R	I	I	R	19
	SIDE STAND					I		I		I	76
*	SUSPENSION					I		I		I	75
*	NUTS, BOLTS, FASTENERS					I		I		I	—
**	WHEELS/TYRES					I		I		I	—
**	STEERING HEAD BEARINGS					I		I		I	—