

## Gauges, Indicators & Displays

---

1	mode switch	This switch is used to select the odometer, tripmeter A and B or digital clock, to adjust the time or to change the speed and mileage units for the speedometer/odometer/tripmeter.
2	reset switch	This switch is used to reset the tripmeter and to adjust the time.
3	right turn signal indicator (orange)	Flashes when the right turn signal operates.
4	high coolant temperature indicator (red)	Lights when the coolant is over the specified temperature. If the indicator comes on, pull safely to the side of the road. See page 167 for instructions and cautions. <i>Lamp Check</i> .
5	fuel reserve indicator (orange)	When this indicator comes on while riding, fuel reserved in the tank is about: <b>0.79 US gal (3.0 l)</b>