


Gauges, Indicators & Displays

Changing the Speed and Mileage Unit

The speedometer displays both “mph” and “km/h.”

The odometer/tripmeter displays both “mile” and “km.”

To select “mph”/“mile” and “km/h”/“km”, push and hold the mode switch (1) for more than 2 seconds with the display in the odometer mode.



(1) mode switch