


2 Changing of mileage unit:

- 1 Press the mode button to select either "km" or "mile".



- 2 Press and hold the mode button.
The mileage unit is set, and then the display returns to the ordinary display.