


Gauges, Indicators & Displays

5. To set the minute, press control button A until the desired minute is displayed. The minute display will return to “00” when “60” is reached without affecting the hour display.

- The time advances by one minute, each time the button is pushed.
- Quick setting — press and hold the button until the desired minute appears.



6. To end the adjustment, press control button B or turn the ignition switch OFF. The display will stop blinking automatically and the adjustment will be cancelled if the button is not pressed for about 30 seconds.