Lap time recall mode

- The history of recorded lap time and the fastest lap time is displayed.
- The lap time is reset.


Fastest lap time (F-LAP) is minimum lap time. Fastest lap time (F-LAP) excludes start and last lap time.

Each time SEL button is pressed, the display is switched F-LAP, LAP-01, LAP-02 ~ (ascending sequence).
Each time SET button is pressed, the display is switched, F-LAP, ~LAP-02, LAP-01

Lap time reset

(descending sequence).

Press and hold SET button to display the "[LER,-"and then press SET button, measured lap time is all reset.



SEL button ⇒ SET button →